

iGasView

MANUAL

CONTENT

01 What's in the box

02 Installing Batteries

03 Preparation

04 Display

05 App Download

06 Setting up device

07 Setting tare weight

01

What's in the box

1 x Weight with display

1 x Strap


1 x Manual



02

Installing Batteries

Slide open the back cover and install 3 x AA batteries (not included) in the slots according to the pictogram.




03

Preparation

Place the scale on a flat surface with a slope less than 3° to ensure that the four legs of the scale touch the ground at the same time.

Carefully place the LPG cylinder on the base.

Hang the display around the neck of the cylinder using the strap.



04

Display

Press the wakeup button to awaken the display terminal. When there is no cylinder on the base, the display will show the digit 0. When a cylinder has been placed on the scale, the display terminal will be showing the weight in real time.

Total weight:

7.5_{KG}

Gas weight*:

2.3_{KG} %

Remaining gas in %*:

55.2 %

Press the “SETUP” button to change between the views


* in order to show remaining gas Tare weight has to be set in the app



05

App download

The GasOkay app can be installed on iOS and Android devices. Find it on App Store or Google Play.



www.igt-lpg.com/gasokay

06

Setting up device

Open the GasOkay app from your phone or tablet.

Click on +Configure new unit

Choose your scale from the list of discovered devices (the device name can be found on a sticker at the bottom of the base)

Give your unit a name so you can easily recognize it, and fill in country and Gas type.

	Name	<u>BBQ</u>
	Country	<u>Denmark</u> ▼
	Gas type	<u>Butane</u> ▼

07

Setting tare weight

When setting up the tare weight you tell the app how many kg to deduct from the total weight to get the actual weight of the gas. The more precise this step is - the more precise we can show you the remaining level of gas.

Simple

In the simple mode you can choose what kind of LPG cylinder you are using - and the app will chose an average tare weight for this type of cylinder.

Advanced

In the advanced mode you can manually set the capacity of the cylinder, the precise Tare weight (normally printed on the side or on the bottom of the cylinder) and the weight of the regulator (which is normally between 200 and 500g)

Press save and the setup is done

Working Temperature	-20 to +40°C
Storing Temperature	-30 to +50°C
Working Humidity	5% to 95%
Weighing Range	1-40 kg
Power Supply	3 x AA Battery



Scan this QR code to reach all EU language instructions

Scannen Sie diesen QR-Code, um zu den Anleitungen in allen EU-Sprachen zu gelangen

Skannaa tämä QR-koodi saadaksesi kaikki EU-kieliset ohjeet

Skanna den här QR-koden för att få instruktioner på alla EU-språk

Сканирайте този QR код за достъп до инструкциите на всички езици на ЕС

Σαρώστε αυτόν τον κωδικό QR για να μεταβείτε σε όλες τις οδηγίες γλώσσας της ΕΕ

Skennja dan il-kodiċi QR biex issib l-istruzzjonijiet bil-lingwi kollha ta' l-UE

Skenējiet šo kvadrātkodu, lai skatītu instrukcijas visas ES valodās

Skenirajte ovaj QR kod da biste vidjeli EU jezične upute

Nuskaitykite šį QR kodą, kad pasiektumėte visas ES kalbos instrukcijas

Scansiona questo codice QR per ottenere le istruzioni in tutte le lingue europee

Scannez ce QR code pour accéder à toutes les instructions dans les langue de l'UE

Olvassa be ezt a QR-kódot, hogy hozzáférhessen minden utasításhoz az EU nyelvein

Escanee este código QR para acceder a las instrucciones en todos los idiomas de la UE

Skannige see QR-kood, et näha kõiki ELi keeltes juhiseid

Naskenujte tento QR kód pro přístup k pokynům ve všech jazycích EU

Naskenujte tento QR kód, aby ste získali pokyny vo všetkých jazykoch EÚ

Scan this QR code to reach the instructions in all EU languages

Zeskanuj ten kod QR, aby mieć dostęp do instrukcji językowych we wszystkich językach Unii Europejskiej


Scan denne QR-kode for at se vejledningen på alle EU-sprog

Scanți acest cod QR pentru a accesa instrucțiunile disponibile în toate limbile din UE

Scan deze QR-code voor alle EU-taalinstructies

Leia este código QR para aceder às instruções em todos os idiomas da UE

Skenirajte to kodo QR za dostop do navodil v vseh jezikih EU



WWW.IGT-LPG.COM



***Integrated Gas
Technologies***

Denmark